

Authority22 Lane Cloth

General Information

No more:

Cutting or unrolling used cloth from the take up roller of your lane machine
Fighting with wet dirty used cloth
Wasted time

Authority22 Lane Cloth has a water resistant core that can be used as the take up roller in your lane machine.

NOTE: First time users of Authority22 Lane Cloth will need to use the existing take up device for used cloth. Route cloth around the cushion roller and attach to your existing take up roll as normal. Once your first roll of Authority22 Lane Cloth has been used proceed with the following directions for installing a new roll of cloth.

New Roll Installation

1. After you have used all of the cloth from the Authority22 supply roll.
2. Remove roll of used lane cloth from the lane machine (save original take up roll if desired).
3. Remove the empty Authority22 water resistant core from the cloth supply position.
4. Place empty Authority22 water resistant core in the take up position for the used cloth.
5. Insert a fresh roll of Authority22 Lane Cloth in the supply position of your lane machine.
6. Feed leading edge of fresh cloth through your lane machine (see routing decal).
7. Allow enough lane cloth to wrap 3 times around the take up core.
8. Remove backing from the unused double sided tape on the water resistant core and attach leading edge of lane cloth.

NOTE: For ease of backing removal, a 1/2" loose strip of backing extends beyond the end of the tape.

9. Rotate take up core until all slack has been removed from cloth. Use machine diagnostics to wind cloth.
10. Finished!