

Barcode Scanner

Programming Codes for Vector Control Desk/POS Systems Barcode Scanner

Unitech Model No. MS331-1U1

1. Remove the barcode scanner from the box.
2. Connect the included cable to the barcode scanner being careful to orient the connector release tab properly.
3. Connect the barcode scanner assembly to an available USB port on the desired machine.
4. Scan the following barcode:



5. The barcode scanner should now be ready to scan membership cards and create/use articles in the Vector POS system.
6. Should it be necessary to remove the cord from the barcode scanner, insert straight pin object, such as a bent out paper clip, into the cord release access hole (refer to the figure below) to depress the release tab on the connector. Gently remove the cord.

